

Instructions:

1. Turn on: Hold down (A)
2. If asked to resume previous game, hit no (A)
3. Set Time: Hit (B)
  - a. Enter amount of time
    - i. Enter 7500 for 1 hour 15 minute game
    - ii. Enter 14000 for 1 hour and 40 minute game
  - b. Hit Enter (C)
4. Start game: Hit (D) at 5:50 for early game, at 7:30 for late game.
5. Operation during game is similar to other controllers.
6. At end of night, turn off: Hold down (A). When controller is off for a certain amount of time, scoreboard will shut off. Do not turn off switch or breakers.

